

DMC 2000 Left Control-side


Abc = Deck A / C Controls

Abc = Global Controls

Abc = If FX 1 is activated

Abc = Deck B / D Controls

Abc = If FX 2 is activated



Note:

To manipulate Tempo Faders on the controller, without changing pitch in DJ software, hold the 'Delete' button and manipulate tempo faders (to set midi controller Tempo Faders equal to the Tempo Faders in DJ software, if necessary)