MICROPHONE MIXER MX870 PHONE JACK TYPE

FEATURES:

- It is good available for singer, party, meeting, P.A. etc....
 Two-channel inputs used for high impedance mic.

3. Four-channel inputs used for low impedance mic.

- 4. Individual volume control to balance each of the six inputs.
- 5. Master volume control to simultaneously control level of all inputs.
- 6. Treble and bass control to adjust the tone.
- 7. It is facility for connecting two or more mixers together to obtain additional microphone inputs.

OPERATION:

- * Please find the six mic. inputs and two outputs at the backside of the mixer, and to connect the all mono plugs which you desired to mix.
- * If you would select low imp. or high imp. mic to insert inputs, please select the impedance to match mic. input of associate amplifier.
- * To connect the AUX (auxoiliary or tape or tuner) input of your amplifier to the OUTPUT of the mixer, two outputs provide high or low level to match amplifier or instrument.
- * Volume 1 to volume 6 By using these volumes, you can gradually increase or decrease each of the six inputs.
- * Tone control To adjust the rotary V.R. of bass and treble to obtain the tone of output.
- * Master volume control: To adjust the rotary V.R. of Master, it will control the output levels.

SPECIFICATIONS:

- 1. Input imp. $4CH-600\Omega/2CH-50K\Omega$
- 2. Low output level: 3mV
- 3. High output level: 0.3V
- 4. Frequency response: 20-20KHz : Under 0.3% 5. Distortion
- 6. Control Knobs : Input Control 6

Treble Control -1, Bass Control -1 Master Control -1, Master Control-1

7. Power Supply: As mentioned on the back side of mixer.